



iPhone 7 Power Button Replacement

Remove or replace the power button in an iPhone 7.

Written By: Scott Havard



INTRODUCTION

Use this guide to remove or replace the power button in your iPhone 7. This guide is just for the physical button, and not the electronic switches beneath.

If you need to replace the volume and power control cable, follow [this guide](#).

Opening the iPhone 7 will damage the waterproof seals on the display. If you do not replace the adhesive seals, your phone will function normally, but will no longer be water-resistant.



TOOLS:

- [P2 Pentalobe Screwdriver iPhone](#) (1)
- [iOpener](#) (1)
- [Suction Handle](#) (1)
- [Spudger](#) (1)
- [iFixit Opening Picks set of 6](#) (1)
- [Tri-point Y000 Screwdriver Bit](#) (1)
- [Tweezers](#) (1)
- [Phillips #000 Screwdriver](#) (1)
- [SIM Card Eject Tool](#) (1)
- [Halberd Spudger](#) (1)
- [Plastic Cards](#) (1)
- [ESD Safe Tweezers Blunt Nose](#) (1)



PARTS:

- [iPhone 7 Case Button Set](#) (1)
- [iPhone 7 7 Plus Power Volume Button Retaining Clips](#) (1)
- [iPhone 7 7 Power and Volume Button Gaskets](#) (1)

Step 1 — Pentalobe Screws



⚠ Before you begin, discharge your iPhone battery below 25%. A charged lithium-ion battery can catch fire and/or explode if accidentally punctured.

- Power off your iPhone before beginning disassembly.
- i** Opening the iPhone's display will damage its waterproof seals. If you do not replace the seals, your phone will no longer be water resistant.
- Remove the two 3.4 mm pentalobe screws on the bottom edge of the iPhone.

Step 2 — Opening Procedure



- i** Heating the lower edge of the iPhone will help soften the adhesive securing the display, making it easier to open.
- Use a hairdryer or [prepare an iOpener](#) and apply it to the lower edge of the iPhone for about a minute in order to soften up the adhesive underneath.

Step 3




- Attach a suction cup to the lower half of the display assembly, just above the home button.
 - ⓘ Be sure the suction cup does not overlap with the home button, as this will prevent a seal from forming between the suction cup and front glass.

Step 4



- Pull up on the suction cup to create a small gap between the display assembly and the rear case.
- Insert the flat end of a spudger into the gap.
 - ⓘ The watertight adhesive holding the display in place is very strong, and creating this initial gap takes a significant amount of force. If you're having a hard time opening a gap, rock the screen up and down to weaken the adhesive until you can fit a spudger inside.

Step 5




- Slide the spudger to the left along the lower edge of the iPhone.
- Twist the spudger to widen the gap between the display and rear case.

Step 6



- Slide the spudger up the left side of the iPhone, starting at the lower edge and moving towards the volume control buttons and silent switch.


 Do not pry along the top edge of the phone, you risk damaging the plastic clips securing the display.

Step 7



- Insert the flat edge of a spudger into the bottom right corner of the device.
- Twist the spudger to widen the gap between the display assembly and the rear case.
- Slide the flat end of the spudger up the right side of the phone to break up the adhesive holding the display in place.

Step 8



- Pull up on the suction cup to lift up the display and open the iPhone.

⚠ Do not raise the display more than 10° as there are ribbon cables along the right edge of the device connecting the display to the logic board.

Step 9



- Pull up on the small nub on the suction cup to remove it from the front panel.

Step 10




- Slide an opening pick along the top edge of the iPhone, between the rear case and front panel, to break up the remaining adhesive holding the screen in place.

 Be careful not to damage the plastic clips on the top edge of the phone.

Step 11



- Pull the display assembly slightly away from the top edge of the phone to disengage the clips holding it to the rear case.
 - Open the iPhone by swinging the display up from the left side, like the back cover of a book.
-  Don't try to fully separate the display yet, as several fragile ribbon cables still connect it to the iPhone's logic board.

Step 12 — Battery Disconnection



- Remove the following tri-point Y000 screws from the lower connector bracket:
 - Three 1.2 mm screws
 - One 2.4 mm screw

Step 13



- Remove the lower connector bracket.

Step 14



- Use the point of a spudger to lift the battery connector out of its socket on the logic board.
- ⓘ Bend the connector cable up slightly to prevent it from making contact with the socket and providing power to the phone.

Step 15 — Display Assembly



- Use the flat end of a spudger or a fingernail to disconnect the two lower display connectors by prying them straight up from their sockets on the logic board.
- ☞ To reconnect these cables, press down on one end until it clicks into place, then repeat on the opposite end. **Do not** press down on the middle. If the connector is even slightly misaligned, the connector can bend, causing permanent damage.

Step 16



- Remove the two 1.3 mm Phillips screws securing the bracket over the front panel sensor assembly connector.
- Remove the bracket.

Step 17



- Disconnect the front panel sensor assembly connector from its socket on the logic board.
- ✦ This press connector should also be reconnected one end at a time to minimize the risk of bending.

Step 18



- Remove the display assembly.
- ✦ During reassembly, pause here if you wish to [replace the adhesive around the edges of the display](#).

Step 19 — SIM Card



- Insert a SIM card eject tool or a paperclip into the small hole in the SIM card tray.
- Press to eject the tray.
 - ⓘ This may require a significant amount of force.
- Remove the SIM card tray assembly from the iPhone.
 - ★ When reinserting the SIM card, ensure that it is in the proper orientation relative to the tray.

Step 20 — Logic Board Connectors



- Use the flat end of a spudger to disconnect the rear-facing camera connector.

Step 21



- Remove the following Phillips screws securing the rear camera bracket to the rear case:
 - One 1.3 mm screw
 - One 2.5 mm screw

Step 22




- Remove the bracket.

Step 23



- Use the pointed end of a spudger to disconnect the camera flash cable connector.

Step 24



- Remove the two 1.2 mm tri-point screws securing the upper cable bracket.

Step 25




- Remove the upper cable bracket.

Step 26



- Use the flat end of a spudger to disconnect the upper cable connector.

Step 27



- Remove the Phillips screws securing the Wi-Fi antenna:

- Three 1.2 mm screws
- One 1.7 mm screw

Step 28



- Remove the top left antenna.

Step 29



- Remove the following Phillips screws:
 - One 1.3 mm screw
 - One 2.2 mm screw

Step 30



- Remove the bracket.

Step 31




- Remove the 2.2 mm standoff screw from the grounding bracket.
- ⓘ You can remove these using an [iPhone Standoff Screwdriver Bit](#), but a small slotted screwdriver will work in a pinch.
- ✦ During reassembly, you can use the tip of a spudger to get the standoff screw started.

Step 32



- Use tweezers to gently bend the logic board grounding bracket out of the way.

Step 33 — Logic Board



- Use the point of a spudger to lift the two antenna cable connectors up off of the sockets on the logic board.

Step 34



- Use tweezers to gently deroute the antenna cables from the metal bracket on the logic board.

Step 35



- Use the point of a spudger to disconnect the lower cable connector.

Step 36



- Remove the following screws:
 - One 1.4 mm Phillips screw
 - Three 2.2 mm standoff screws
- ① You can remove these using an [iPhone Standoff Screwdriver Bit](#), but a small slotted screwdriver will work in a pinch.

Step 37




- Use the point of a spudger to move the SIM card eject plunger out of the logic board's way.

Step 38



- Use the flat end of a spudger to gently lift the battery connector end of the logic board up.
 - ⓘ Make sure you're not pulling against any cables. If you feel resistance, check all cables, connectors, and components are clear of the board.


Step 39



- Lift the battery connector end of the logic board and pull it up and out of the rear case.


⚠ Be careful not to snag the logic board on any cables.

Step 40 — Power and Volume Control Cable



- Remove the following Phillips screws:
 - Two 1.9 mm screws securing the power button.
 - Three 2.3 mm screws securing the volume buttons.

Step 41



- Remove the following 1.3 mm Phillips screws:

- One screw beside the rear-facing camera
- One screw on the rear case

Step 42



- From the outside of the phone, push the hold switch into the rear case with the point of a spudger.
- This action will free the hold switch and gasket from the rear case.

Step 43




- Use a pair of tweezers to remove the rear-facing camera.

Step 44




- Moving from power button side of the phone, use an opening pick to separate the adhesive holding the antenna flex cable to the rear case.

Step 45



- Slide the point of an opening pick underneath the antenna flex cable towards the top of the phone, separating the remaining adhesive.

Step 46



- Use tweezers to move the antenna flex cable away from the edge of the phone, freeing the screw bracket from the rear case.
- Remove the antenna flex cable.

Step 47



- Remove the 2.3 mm standoff screw securing the flash bracket to the rear case.
- ⓘ You can remove these using an iPhone Standoff Screwdriver Bit, but a small slotted screwdriver will work in a pinch.

Step 48



- Remove the flash bracket.

Step 49



- Use the point of a spudger to gently unseat the flash module.

Step 50



- Use the blade of a Halberd spudger to separate the adhesive holding the microphone to the rear case.

Step 51



- Gently fold the power button module from the edge of the rear case.

Step 52



- Slide the blade of a halberd spudger under the power button end of the button cable to separate it from the adhesive on the rear case.
- Continue to separate the adhesive by moving the blade towards the top of the phone.

Step 53



- Continue to move the blade of the halberd spudger underneath the power and volume control cable.

⚠ Move slowly to make sure that the cable is not damaged during removal.

Step 54



- Slide the halberd spudger under the volume control portion of the button cable.
- Gently slide the blade underneath the cable towards the bottom of the phone, separating the remaining adhesive.

Step 55



- Remove the power and volume control cable.

Step 56 — Power Button



- Pull the clip towards the bottom of the phone and lift up to free it from the bracket.

Step 57



- Remove the clip from the rear case.

Step 58



- Push the lower end of the power button bracket up off of peg securing it.

Step 59



- Pull the bracket from the rear case.

Step 60



- Use the pointed end of a spudger to push the power button cover out of the rear case.
- Remove the power button cover.

To reassemble your device, follow these instructions in reverse order.

